



- SafetyCope is laid on a two-part adhesive and pressed into place.
- A thin mastic bead is used to butt the copings together.
- The same mastic is used for the joints & edge of the copings.
- A fine toothed hand saw is used should the safety copings need to be cut
- Eliminates the need for petrol/electric disc cutters.

