



globalresins ltd

Park Lane Industrial Estate, Corsham. Wiltshire. SN13 9LG
Tel: 01249 715566 Fax: 01249 715533 E-Mail: office@globalresins.co.uk
www.globalresins.co.uk www.safetycope.co.uk

MIXING INSTRUCTIONS

PU200 WINTER

If possible, keep out of direct sunlight and keep as cool as possible.

Before following the instructions below it may be necessary to mix the resin with a stick or spatula in order to loosen any sand at the bottom of the can.

Mix the resin using a whisk attached to an electric drill for between 1 and 2 minutes until all the sand has been mixed with the liquid. This action will generate some heat, so on very warm days it may be advisable to allow the cans to stand for a while to allow the heat to dissipate.

Then pour ALL of the hardener into the resin and mix immediately for between 30 seconds and a maximum of 45 seconds (the colder the ambient temperature, the longer the mixing time required - i.e. below 5°C). Ensure all the hardener is mixed into the resin.

Then pour the mixed systems **IMMEDIATELY** into the slot.